

Soundcraft Notepad Specs

Inputs

Mic/Line (Channels 1-4): 4 x combo
XLR-1/4" / 6.35 mm
Line (Channels 5-6): 2 x 1/4" / 6.35
mm
Line (Channels 7-8): 2 x 1/4" / 6.35
mm
Line (Channels 9-10): 2 x RCA
Line / External FX (Channels 11-12):
1/4" / 6.35 mm

Outputs

Master (L/R): 2 x XLR
Aux: 1 x 1/4" / 6.35 mm
Headphone: 1 x 1/4" / 6.35 mm

Controls

Gain (Channels 1-4): 4 x Gain knobs
Trim (Channels 5/6 & 7/8): 2 x Trim
knobs
Aux Send (Channels 1-4, 5/6, 7/8,
9/10): 7 x Aux/FX knobs
Pan (Channels 1-4, 5/6, 7/8, 9/10,
11/12-FX RTN): 8 x pan knobs
Level (Channels 1-4, 5/6, 7/8, 9/10,
11/12-FX RTN): 8 Level knobs
Master Level: 1 x fader
Aux Master: 1 x Aux Master knob
Headphone Level: 1 x knob
Parameter: 1 x Parameter knob for FX
Tap Tempo: 1 x button
Output Type: Button for mono line
out or stereo headphones
Headphone Input: 1 x button for
Master or USB Return 3/4

EQ Controls

3-Band EQ (Channels 1-4)

HF: ± 12 at 12 kHz
MF: ± 12 at 2.5 kHz
LF: ± 12 at 80 Hz

Effects
Karaoke
Delay
Chorus
Reverb

USB
Connector: Type-B
Sound Card: USB 4 x 4

Indicator LEDs
Meters: 4 x LED (-20, 0, +6 dB, Peak)
Delay Tap Tempo: 1 x LED

Dimensions
Not specified by manufacturer

Weight
Not specified by manufacturer

Packaging Info

Package Weight
4.705 lb

Box Dimensions (LxWxH)
13.6 x 12.05 x 3.6"
