



# ANGEKIS ASP-04D-4S

## Anti-magnetic design

Wooden Digital active speaker, Mellow mid-range and strong bass.

## Wireless portable microphone

Stable communication and smooth communication. Clear sound quality no noise and no harshness

## Full-duplex

Voice processing technology 3606 high coverage Smart pickup 384ms echo canoellation

Full-duplex call technology Dynamic noise reduction

# Support handheld microphone

The connection is stable and continuous, so that the sound car



## Wireless charging

While using traditional wired charging, a single omnidirectional microphone also supports wireless charging function, two chargin methods are selected, which is more convenient to use.

### ASP-04D-4S

#### Specification

#### Component:

 Omni-directional desktop controller with audio processing functions and USB function control, indicators and buttons

- Digital Active Speaker
- USB data cable
- USB charging plug
- Built-in battery

#### Size

- 110\*110\*20 mm (omnidirectionl mic)
- 410\*210\*150mm (loudspeaker)

#### Net Weiaht

- Single microphone: 200g
  - Loudspeaker: 4.7kgs Color
- Microphone: Business Black Speaker
- · Matte black painted panel
- Black piano painted wooden side
- Omnidirectional microphone
- Audio bandwidth
- 100-16KHz
- Sensitivity: -38 dB 94dB SPL@1KHz
- Signal to noise ratio: 65dB
- 94dB SPL @ 1KHz, A-weight
- Power supply
- DC 5V / 500mA
- Built-in 1800mA lithium-ion battery

#### Active speakers

- Power:mid-bass 25W\*2, High pitch 10W\*1
- Volume: 100dB (0.5m)
- Power adapter: 15V/4A
- Speaker frequency response: 75HZ ~ 20KHZ

#### Audio

- Digital audio processing
- 384ms echo cancellation
- Dynamic noise reduction
- full duplex
- 360 degree pick-up range
- Up to 3m pickup range Computer system
- Windows 8 / Windows 7 / Windows 10/Windows
- XP., mac 10.7 and above, etc.

#### Audio

- support computer software audio
- Team, Zoom and etc.
- microphone mute
- loudspeaker mute
- volume up/down
- indicator

#### Product

#### execution standard

- YD/T 993-1998
- GB/T 9254-2008
  - GB 4843.1-2011

#### Recommended

#### conditions

- temperature: 5°-44°
- humidity: 20-85% condensation free
- noise level: <48db
- storage temperature: -10°-55°
- Reverberation time: <0.5 seconds

#### Omnidirectional

#### microphone button

- Speaker mute button
- Microphone mute button
- Volume up button
- Volume down button
  Turn on/off button

#### Speakerphone indicators:

#### Switch on/off:

Press and hold the switch button on the bottom of speakerphone for 1 second to turn on; press and hold the switch button on the bottom of speakerphone for 1 second to turn off

#### Low battery:

1.When the speaker is not turned on, the green light of one of the speakerphones flashes, if other speakerphones do not flash, it means that this speakerphone has low power.

2.In the online state, when the power is low, the red light of the speakerphones will flash.

Charging: The charging indicator of the speakerphoes are orange.

Charging completed: the charging indicator turn off. Normal connection: the green light of the speakerphones are always on, and the indicator light of the master is green Not connected normally: When the master is not turned on, the speakerphones status is green and blinking.

Microphone mute: the red light of the speakerphone is always on

Speaker mute: the indicator light on the host is steady red Speaker indicator

Green light: The device is working normally Speaker volume adjustment knob

- To the Left: Volume down
- To the right: Volume up